

Scandisk shows no bad sectors. I have checked for hardware failures, but all seems OK. I have four other similar PCs, and all have the same problem.

Himanshu

A To resolve the issue, use Notepad to open the scandisk.ini file within the Windows\Command folder. In this file, search for the [Environment] section. Within this section, modify the lines for ScanTimeOut and NumPasses as below:

```
ScanTimeOut=On
NumPasses=5
```

If the [Environment] section is missing, add the section at the bottom of the file as below:

```
[Environment]
ScanTimeOut=On
NumPasses=5
```

Save and close the file, then restart the computer in DOS mode. At the prompt, execute scandisk. Repair any errors. After scandisk is done, type in "exit" and hit [ENTER] to get back to Windows. Run Defragmenter again. If the error persists, run Defragmenter to only consolidate free space. After that, defragment files only, and then perform a full defrag (both files and free space).

In order to run Defragmenter to only consolidate free space, click **Advanced**, click **Consolidate Free Space Only**, and then click **OK**. When Defragmenter completes, do not quit: instead, click **Advanced**, click **Defragment Files Only** and then click **OK**. Once again, do not quit when Defragmenter completes—click **Advanced**, click "Full defragmentation (both files and free space)," and then click **OK**. This should solve your problem.

If it does not, contact the manufacturer of your computer or hard disk to enquire about additional workarounds that may correct the problem.

Menu Names In Photoshop CS Show Up In A Foreign Language

Q I have installed Photoshop CS as well as ImageReady. The problem is that Photoshop does not show menu names in English, while ImageReady does. How do I solve the problem?

Cyril Barot

A You need to add or modify the following registry keys. Copy the following lines into Notepad and save the file with a .reg extension. Close the .reg file, then double click on it. This will add the lines to the registry. Photoshop should now be OK.

```
HKEY_CLASSES_ROOT\Interface\{9414F179-C905-11d1-92CC-00600808FC44} = IPhotoshopApplication
HKEY_CLASSES_ROOT\Interface\{9414F179-C905-11d1-92CC-00600808FC44}\TypeLib = {4B0AB3E1-80F1-11cf-86B4-444553540000}
HKEY_CLASSES_ROOT\Interface\{9414F179-C905-11d1-92CC-00600808FC44}\ProxyStubClsid32 = {00020424-0000-0000-C000-000000000046}
```



sos@jasubhai.com

E-mail us your computing problems, and we may answer them here! Since we get more mails per day than we can handle, it may take some time for your query to be answered. Rest assured, we are listening!

It's Just The Battery

Q My processor is a Pentium 4 2.4 GHz. When I turn on my computer, the first screen shows up the following error: "CMOS CHECKSUM ERROR-Defaults Loaded. Press F1 to Continue."

When I press F1, the system boots up and works properly, but the clock tells the wrong time. When I change the CMOS settings from the BIOS and restart the system after some time, it displays the same error message.

Is this a jumper setting problem? What can I do to make the error screen go away?

Sanjeev Nehra

A The CMOS checksum error flashes on the screen when the CMOS batteries drain out. Just replace the CMOS battery.

RAM Stick Compatibility

Q I have a P4 1.7 GHz, 128 MB of PC133 SDRAM, and a GeForce 4 Mx-420 64 MB video card. I want to attach another 128 MB SDRAM stick of the same speed (PC133). But every time I put it in, no programs work properly, especially games. But when I use only the new stick, programs work fine.

Sandeep

A There is a compatibility problem between your older and recently purchased memory modules. The speed of the memory modules being the same does not necessarily mean they have identical characteristics at the chip level. For example, check the CAS latency of the two memory modules. We recommend that you replace your old memory module, and use a brand new set.

Low 3DMark 2003 Score

Q I have a P4 2.8 GHz HT (LGA775 Socket), an original Intel 915GAV, a 512 MB Hynix DDR 400 MHz RAM stick (single channel), and an 80 GB Seagate Barracuda hard disk. The OS is Windows XP with SP2, and with all the latest patches and updates. I've updated Norton AntiVirus 2004 with Norton Internet Security. Despite having the latest hardware and software updates, my 3D Mark03 score is only 265.

Will upgrading to dual-channel memory be worth the money?

Sandip Padte

A A score of 265 in 3DMark 2003 is low. We think there may be a settings problem or a driver problem. Also, when you were benchmarking the system, what programs were running in the background? Norton AntiVirus and Internet Security should ideally not be running—they take up a lot of resources. Check the driver version of the onboard graphics adapter and see if Intel has released any new versions. If it has, download and install them. There is also the possibility that SP2 is responsible for the low 3DMark 2003 score. ☐