

the case with the included hardware, or you can find a spot where you could velcro it in place. Usually, the hard drive cage would turn out to be a good candidate for the purpose.

After deciding on where the parts would go, you should then decide how you'll run the tubing. Starting from the pump, you could lead to the radiator and then the waterblock, before looping it back to the reservoir. Or else, you could first go to the waterblock, then the radiator and back. There isn't much of a difference between the two in terms of performance, so go for whichever fits easily.



Rinse. Dry. Repeat.

2. Rinsing out the components

This is the part where you get all the hardware and then rinse it.

For the reservoir, tubing and waterblock, this amounts to just running distilled water through it. For the radiator, it can be complicated. Since radiators often come

with some debris left over from the manufacturing within, you should rinse it thoroughly.

You can do this by heating up some distilled water before pouring it in the radiator. You can fill it some two thirds of the way up. After plugging the holes up, shake it well for a couple of minutes. Then drain the water. Debris would be mixed with it. Repeat the process until you get clear water coming out.

3. Installing the hardware

To mount the waterblock on the CPU, do this: Add a little thermal paste on the CPU before setting the cooler on top of it. Then, attach the backplate to the motherboard's backside and then screw the plate in place. While screwing it in, ensure that you give each screw just a few twists at a time. You should also move in the star pattern – so that the pressure comes across evenly on the processor.



The perfect loop starts at the drawing board!