

A This is Windows' "hibernate" file. It stores the contents of your RAM when you put your computer into hibernate mode, so its size is equal to that of the RAM installed. You cannot just delete this file; it is locked by Windows.

Your computer is currently configured to be able to hibernate. If you want to remove the hiberfil.sys file, you'll need to disable hibernation: open the Control Panel. Double-click Power Options. Click the Hibernate tab, de-select the "Enable hibernation" checkbox, and click Apply. Restart your computer, and the hiberfil.sys file will be automatically deleted. Note that you now won't be able to hibernate your PC.

Driving Me Crazy

Q I recently bought a Nokia 6600. I am unable to use it as a modem to access the Internet on my PC. The modem is detected, but when I dial, it gives an error: "Error 777: modem on the remote computer is out of order." Is the modem in the phone faulty, or am I doing something wrong?

Karan Lodhi

A In all probability, you have installed your modem with an incorrect driver. Install the drivers either from the driver CD that came with your Nokia 6600, or download and install the latest drivers from www.nokia.com.

Help Needed—Literally!

Q I installed Windows Vista RTM and it runs very well. I have several old WinHelp files (files with the .hlp extension). When I double-click to open these files, I see a message that I can download a Vista version of WinHelp from Microsoft. When I follow the link, I find that no such download exists. Where can I find them?

Bikram Ramani

A Open Windows Explorer. Go to your Windows folder (C:\Windows), and locate the existing winhlp32.exe. Right-click on the file, select Properties, and choose the Security tab. Click on Advanced, go to the Owner tab, and click Edit. Select your user name in the list, and then click OK four times to close all the Properties and Security windows. Right-click on the winhlp32.exe file again, select Properties, and then go to the Security tab again. Click Edit, then on Administrators in the list, and place a checkmark next to "Full control" in the Allow column. Click Yes, and then on OK in each of the two open Properties and Security windows.

Next, get the Windows XP SP2 version of winhlp32.exe. The size should be 283,648 bytes, and the version number should be 5.1.2600.2180. You can get it from any PC running Windows XP SP2, or from a Windows XP disc.



Drag and drop the XP SP2 version of winhlp32.exe into your Windows folder, replacing the Vista version that's there.

If you're not the Administrator of your PC, you won't be able to replace the Vista version of the winhlp32.exe file that came with XP SP2. Just leave the XP version of winhlp32.exe on your Desktop, and then just drag and drop .hlp files onto it to view them.

When DLLs Go Bad

Q I have Windows XP Professional, and have recently installed Windows Media Player 11 from the *Digit* CD. An error message pops up when I try to start WMP 11: "An internal application error has occurred."

Ajit Mankad

A The first possible reason for this happening is that the component registration for the Jscript.dll file or for the VBScript.dll file is corrupt; the second is that one or both of these files have become unregistered. The solution is to re-register the Jscript.dll and Vbscript.dll files. To do this, start the command prompt (Start > Run > cmd > [Enter]) and run the commands "regsvr32 jscript.dll" and "regsvr32 vbscript.dll".

A Burning Question

Q I have a P IV with 1 GB of RAM and Windows XP Pro SP2. I have a Sony CD-RW which has performed very well thus far. But for the past few days, I have not been able to burn any data using the drive. It shows up as a CD-ROM drive in Windows Explorer, and the Recording tab is not displayed in its Properties dialog box.

Mahesh Kumar

A A recordable drive is sometimes recognised by Windows as a non-recordable device, and this can be easily solved. Follow these steps after opening the Registry Editor:

1. Navigate to the sub-key `HKEY_CURRENT_USER\Software\Microsoft\Windows\CurrentVersion\Explorer\CD Burning\Drives`
 2. Go to File > Export, type in "Drive key backup" in the dialog box, and click Save.
 3. In the left pane, click on the "Volume{GUID}" folder under Drives ("GUID" here is a 32-character hexadecimal value).
 4. Double-click on Drive Type in the right pane. In the Value data box, enter "2" and click OK.
- Quit the Registry Editor. Windows should now recognise the drive as a CD-RW drive.

A Control Freak

Q I have upgraded to Windows XP from Windows 98, and many icons in the Control Panel do not show up at all. How can I restore them?

Shashank Mathur

A This is caused by a bug in Windows XP where certain Registry settings left over from previous versions are misinterpreted. Here is how to (easily!) fix the problem: in the Registry Editor, navigate to `HKEY_CURRENT_USER\Control Panel`. Delete the "don't load" key entirely, and close the Registry Editor. The missing Control Panel icons should appear immediately. ■