

Start your radio station

Always thought you could do a better job than that local radio jockey? Now you can, with the help of our workshop

Tips & tricks

Get the latest jazz on Lightroom 5, mind you it's still in beta, and a few steps to refresh your not-so-new smartphone

Switching GPU, erratic 3D, recovering data, and rejuvenating an old HDD

Just some of the SOS and Help messages sent our way during the month

GPU swap

Hi,
I have an HCL Beanstalk AIO MA380 PRO ADIV0028 with 2GB DDR3 RAM, Intel HD Graphics 3000. I want to install a new GPU "gainward NVIDIA 2GB DDR3 GT610." Can I install this graphics card on my computer? Please help me

Rahit

A All-in-ones generally come with the graphics components fused onto the board. Unlike a normal desktop PC, which has PCIe slots for cards, on the AIO, the graphics card will be fused onto the board. But just to be on the safe side, enquire with HCL regarding the same.

Wi-Fi woes on laptop

Dear Digit,
Hello! I have a problem in my laptop's wireless driver. I had Windows 7 Ultimate, but after installing Windows 8 Pro I could not connect to Wi-Fi. In fact my laptop doesn't detect any available Wi-Fi signal.

System Configuration:

- Dell Inspiron n-SERIES - N5010
- Windows 8 Pro
- Intel(R) Core(TM) i3 M380 @ 2.53 GHz
- 64-bit Operating System
- 4 GB RAM

I have attached a photo of device manager in which there is a yellow triangle on Intel(R) Centrino(R) Wireless-N 1000. As shown in second photo, I have updated the driver from internet, but after that also, there is no improvement.

Nikunj Naliyapara

A You'll need to use the drivers that came bundled with your laptop. The ones that work on Windows 7 should work on Windows 8 as well. Alternatively, call up Dell technical support as they have a very competent support network that will be able to help you out. Please do remember that Windows 8 is still having some

compatibility issues with certain hardware and if your device is unsupported, it may be some time before you get the proper drivers.

3D Vision gone fuzzy

Here is my configurations:

- CPU: AMD Phenom 2 x545
- RAM: 4GB DDR2
- GPU: Radeon HD 6670 2GB DDR2

I bought a new NVIDIA 3D Vision last month and connected all the cables and installed all the drivers, but an error appeared prompting me to download the latest NVIDIA graphic drivers. But I don't have an NVIDIA GPU. So what should I do? Should I buy an NVIDIA graphic card?

Gourav Godara

A No, you can't run 3D Vision kit using an AMD card, as it requires NVIDIA cards only since the NVIDIA drivers are specifically written to communicate with the 3D Vision kit. Also what monitor do you have? Is it a 3D monitor? Check out this link (<http://digit.in/11BsFMk>) for supported monitors and NVIDIA GPUs that can run your 3D Vision kit. Also if you plan to play 3D games, especially the latest ones, we would suggest you go for a mid-range NVIDIA GPU as stereoscopic 3D is very demanding with GTX 560Ti at the very least.



NVIDIA 3D Vision glasses

Overclocking hassles

Hello, TeamDigit. I am facing problems with my old PC. My brother tried to overclock my father's old PC to 3.3 GHz with the stock fan and 1 GB RAM @ 400 MHz. Now when I



Bringing new lease of life to an old HDD

switch on my PC it shows no signal without even the boot sequence displayed. Please, help me restore the CPU speed to 2.2 GHz. My system configurations are:

- CPU: Intel Pentium @ 2.2 GHz
- G31 chipset Biostar motherboard
- RAM: 1 GB @ 400 MHz.

Guining Pertin

A Try clearing the CMOS and then trying again. It will set your system to stock settings.

Wonky software uninstall

I have Windows 7 installed on my laptop. I uninstalled Windows Media Center because it was not working properly from Control Panel > Programs and Features > Turn Windows features on or off > Media features > Windows Media Center. After uninstalling I tried to install it again in the same way. But then it says - An error has occurred. Not all features were successfully changed. To solve this problem I don't want to re-install Windows because I don't want to install all the software again. Please help.

Joswin Concessao

A Did you select both Windows Media Centre and Windows Media Player. Deselected them under Media Features and then restart the system after applying