

2.2: Choosing the Right Equipment

If you are planning to connect two PCs placed in different rooms, you have two options. The first is to connect them in Infrastructure mode using an Access Point. The Access Point or Base Station will act as a trans-receiver for both the PCs. The other option is to connect the PCs in Ad-Hoc mode, where you do not

need an Access Point. Here, the radio cards will connect directly with each other. Performance with Ad-Hoc mode is not going to be as good as with an Access Point as the distance increases and there are more hindrances between the two wireless cards.



A cable with RJ45 connectors at both ends

You need to choose from various standards available in the market depending on the data throughput you need. If you are going to stream a movie, then 802.11g, which supports 54 Mbps throughput speed, will be required. However, if you are planning on just sharing files and folders and listen to MP3s, then the older, slower and now cheaper 802.11b hardware supporting 11Mbps is sufficient.