

like PPPoE (Point to Point Protocol over Ethernet), your user name and password which is provided by the ISP, subnet mask, default gateway, and so on.

When you log in to the Web server of the router, you will be asked to give this information. If the broadband router asks for any additional information, you will have to get it from your ISP. Once you have provided all the necessary information, use the test button to check whether you are able to connect to the Internet.

Sharing An Internet Connection Using An Access Point

When you have plugged a simple Access point to your PC with a dial-up connection to connect to the internet, you will have to use third-party software to share internet. We will take the example of SyGate, which is a widely used Internet sharing program. Internet connection software needs to be installed on both the server and the client. Once you are through with the installation on the server—where the dial-up modem and Access Point is connected—and the client system (where the PCI wireless card is connected), the rest of the installation is straightforward.

For the setup mentioned above, leave 'Use Single NIC mode' option unchecked. SyGate will show the appropriate connections in 'Direct Internet/ISP Connections', as well as '1' in 'Local Area Network Connection'. The 'Direct Internet/ISP Connections' would have a 'Local Area Connection' if you have more than one LAN card or dial-up connection. To share a dial-up connection, you would first have to set up one in Windows, and then add it in SyGate.

Now select the LAN card that connects your PC to the Access Point in '1' within 'Local Area Network Connection'.

Once the above step is complete, your configuration is done. But there are further settings to look at, for better optimisation of Internet bandwidth and system resources.

Dial-On-Demand and Auto Disconnect are two settings that