

The procedure to install a LAN card is similar to that of installing a PCI card. Install the card in any free slot and after you have checked that the card fits snugly into the slot, attach a screw on the top of the card. Then start up the computer and Windows XP will automatically detect the new hardware and ask you for the drivers. The rest of the steps to be performed are as follows:

1. Click on 'Start' and highlight 'All Programs'. Go up to 'Accessories' and scroll over to 'Communications' and click on the 'New Connection Wizard'.
2. The next window is the 'New Connection Wizard', similar to what we have seen earlier during the configuration of the modem. Click 'Next' to continue.
3. This window similar to the one explained in the modem configuration window that lets you specify the network connection type. By default, the option 'Connect to the Internet' is chosen. Click 'Next' and continue.
4. In the next window, you are asked to select how you would like to connect to the Internet. Choose the second option by clicking in the radio button next to 'Set up my connection manually' and click 'Next'.
5. In the ensuing window, choose the last option which is 'Connect using a broadband connection' that is 'always on'. Unlike a dial-up connection, a LAN or broadband connection will always remain on, hence this option. Once again, click 'Next'.
6. On the next window, click on the 'Finish' button and the connection is created.

