

PCI-Express video cards have already entered the market and low end cards are abundant in the market, and retail for about Rs 5,000 to Rs 6,000. Higher end PCIe cards are available, but for exorbitant prices.

Installing a video card is similar to installing a PCI card; however, you need to remember some points.

1. If you have an older AGP card such as the SiS 6326 or an nVidia Riva TNT/TNT2, or a Savage Voodoo, these cards may not install on newer motherboards with AGP slots, as the voltage requirements of the older cards is higher than those available now. So your old video card will be better off in your old machine. Get a new card for your new machine.
2. Follow the instructions as for installing a PCI card for installing the AGP card, except that you will need to check if the lock of the video card has clicked into place.

Locate the AGP slot as shown

