

specifying the type of port, manufacturer name and model number—as and when it asks for these details. Finally, print a test page to confirm that everything is fine.

You may need to install the printer driver if the wizard asks for it. The CD-ROM that comes with the printer will have the necessary driver files.



Adding a Network printer using Add Printer Wizard is very simple. All you need is the network path to the printer

4.4.2 Adding A Network Printer

Installing a network printer is very simple provided you know the “path” of the printer. Say your computer is on a Windows network, and a local printer is connected to a PC called “PCName”, and the name of the printer is “PrinterName”. This local printer will serve as a network printer for your PC.

Start the printer Wizard as mentioned earlier. Choose ‘Network Printer’ and click ‘Next’. Now you can either browse for a printer, which is rather tedious task, or you can just enter the path in the ‘Connect to Printer’ option. In our example, the path would be \\PCName\PrinterName. A message saying “You are about to connect to a printer on PCName, which will automatically install a printer driver...” will appear when the network printer is located successfully. You will be prompted to print a test page.

If you face problems during installation, make sure the path you specified is correct—contact your network administrator for details. Problems could also arise if the PC that the network printer is connected to is turned off, or if a Firewall is disallowing connections from your machine. These problems can be addressed by a network administrator or the person handling the network printer.