

► **Problem:** The system can't detect either of two drives connected on the same channel.

Cause: This occurs when both drives are set to either Master or Slave.

Solution: Check the jumper connection on both devices and set one as the Master and the other as the Slave. In newer motherboards, you can set both the devices to cable select—this takes care of the problem in an efficient manner.

► **Problem:** There is a large number of .CHK files in the root directory of the drive.

Cause: .CHK files are created by the SCANDISK and CHKDSK utilities when they scan the system for lost allocation units.

Solution: You can safely delete all .CHK files after searching for them. It's only when the PC is not shut down properly that these .CHK files are created by the two scanning utilities. Hence, always switch off the PC properly, i.e., don't reboot the machine by pressing the reset button on the front panel.

► **Problem:** You're unable to view a SATA hard drive during Windows XP installation.

Cause: Windows XP loads the required drivers before it begins to copy the files necessary for installation. Motherboard chipsets lacking native support for SATA drives are not recognised during the installation. You'll have to manually load the drivers before the file copying starts.

Solution: Such motherboards come bundled with a floppy drive that contains the necessary SATA drivers. While loading Windows XP, at a certain stage, i.e., before loading generic drivers into memory, you're prompted to press [F6] for installing additional device drivers. Press [F6] once the generic drivers are loaded. The system will prompt for the floppy disk containing the SATA drivers; insert the floppy disk and then load the appropriate driver for XP. Once this is done, Windows XP will recognise SATA drives during setup.