



Game Controller

USB headers that require to be connected to separately provided USB ports. Install the USB header cables and the USB ports will be ready to use.

► **Problem:** A USB game controller doesn't work with some older games.

Cause: The USB game controller might not perfectly emulate game port-based controllers.

Solution: Check with the game controller manufacturer for updated drivers, patches or workarounds.

► **Problem:** You can't use a USB keyboard and mouse outside of Windows.

Cause: USB legacy support is disabled in BIOS.

Solution: Enable USB legacy support. You can do this under the Integrated Peripherals setup in the BIOS.

► **Problem:** You cannot use any USB devices—they are not detected.

Cause: USB is disabled, or not assigned an IRQ.