

Recommended Resolution: (a) Restart the computer. If that doesn't solve the problem, copy the installation files to the hard disk and run the setup program for the device.

(b) Remove the device from Device Manager and reinstall it using the Add Hardware Wizard.

Code 33

Code Meaning: (a) The hardware is not responding to the driver software for the device.

(b) The software that determines the resources required by the device has failed.

Recommended Resolution: (a) Obtain an updated driver from the manufacturer. Remove the device from Device Manager and reinstall it using the Add Hardware Wizard.

(b) The hardware might have failed and needs to be replaced.

Code 34

Code Meaning: The device has to be configured manually.

Recommended Resolution: Refer to the manufacturer's documentation for instructions.

Code 35

Code Meaning: The BIOS is missing a resource assignment entry for the device and needs to be updated.

Recommended Resolution: Obtain and install a new or updated BIOS from the computer manufacturer or motherboard manufacturer.

Code 36

Code Meaning: The IRQ configuration has failed.

Recommended Resolution: Refer to the motherboard documentation to see if you can change the IRQ settings in the BIOS. See the BIOS section of this guide for further information.