

all jumpers are properly configured.

Eight beeps: Display memory read/write failure

Problem: The BIOS is not able to read/write the display card's memory.

Solution: Troubleshoot the motherboard and/or display card.

Nine beeps: BIOS' ROM checksum failure

Problem: The BIOS CMOS chip is most likely defective. May also be a problem with the motherboard.

Solution: The CMOS chip can be replaced, but replacing the motherboard is simpler and more cost-effective.

10 beeps: CMOS shutdown register read/write error

Problem: A motherboard component is creating an error when interacting with the CMOS.

Solution: Troubleshoot the motherboard and verify that all components are properly set up and configured.

11 beeps: Cache memory error

Problem: There is an problem with the processor's L2 cache.

Solution: Verify that the L2 cache chip is inserted correctly. Verify that all connections inside the PC are correct. Replace the cache module if the problem persists.

Continuous beeps: Video / Memory problem

Problem: A problem with the RAM, display card or motherboard.

Solution: Troubleshoot the RAM first, followed by the display card and then the motherboard.

Other beeps: Check motherboard manual

Problem: Check the motherboard manual or the vendor's Web site for more information. Treat it as a motherboard problem.

Solution: Troubleshoot the motherboard.

2.2.2 Award BIOS

Award has the least number of documented beep codes. They pre-