

- You must have a 48-bit LBA compatible BIOS
- Your hard disk must be larger than 137 GB

Performing the tweak on systems that do not meet these requirements WILL result in data loss! You have been warned!

Speed Up The COM Port

By default, all Windows 95/98/NT4/2000/ME/XP releases allow only up to 9600 bps on all serial ports: COMx = COM1–COM9 [BIOS (hardware) ports: COM1–COM4 ; Virtual (emulated) ports: COM5–COM9].

These settings enable serial (analogue) modem throughput over 9600 bps, to *possibly* speed up Internet access.

H L M \ S O F T W A R E \ M i c r o s o f t \ W i n d o w s
NT\CurrentVersion\Ports

Modify the default String Value of the port. For example, COM1 is “9600,n,8,1” by default; you can modify it to “921600,n,8,1,p”.

WARNING: Do this **ONLY** IF using dial-up (analogue) modems (e.g. 56K, ISDN) connected **ONLY** to a Serial Port (COMx), **NOT** IF using xDSL, Cable, Satellite, CNR, USB or Network (digital) modems! If using internal modems located in the Communication Networking Riser (CNR) slot, do **NOT** use these settings! Such cards are incompatible with these settings.

Also, please don't *expect* your Internet access speeds to improve—if they do, well and good!