

1024, L: 2048, M: 4096, N: 8192, O: 16384, P: 32768, Q: 65536, R: 131072, S: 262144, T: 524288, U: 1048576, V: 2097152, W: 4194304, X: 8388608, Y: 16777216, Z: 33554432, All Drives: 67108863

For example, to hide drive A and drive C, you would add 1 (for A) + 4 (for C) to get 5, and the value of NoViewOnDrive should be set to 5. To disable all drives, set the value to 67108863.

You'll need to restart Windows for the change to take effect.

Disable Shutting Down

You can prevent users from being able to shut down the computer. This might be useful in cases such as when you're running a server and you don't want anyone to shut it down inadvertently.

Navigate to:

HCU\Software\Microsoft\Windows\CurrentVersion\Policies\Explorer

And to:

HLM\Software\Microsoft\Windows\CurrentVersion\Policies\Explorer

In these locations, create or modify the DWORD value called NoClose and set it to 1. Reset it to 0 to enable shutting down.

Log out and log back in, or restart Windows, for the change to take effect.

Restrict Access To Windows Update

Again, if you don't want your friends (or enemies) to make any changes to your system, you can consider, amongst other things, changing a Registry setting to restrict access to Windows Update.

Navigate to:

HCU\Software\Microsoft\Windows\CurrentVersion\Policies\Explorer