

If you create a new sub-key named WinOldApp, you can add the following DWORD values under it, and set them to 1 for enabling the option and to 0 for disabling it.

Disabled: Disable the MS-DOS Prompt

NoRealMode: Disable Single-Mode MS-DOS

8.2 Network-Related Hacks

Stop Automatically Detecting Network Connection Speed

Windows will normally attempt to detect the time-out on network links to determine their speed (high or low). This functionality can be disabled if Windows is having problems determining the speed of your link.

Navigate to:

HLM\SOFTWARE\Microsoft\Windows NT\CurrentVersion
\Winlogon

Create or modify the DWORD value called SlowLinkDetectEnabled and set it to 0 to disable the functionality or to 1 to enable it.

Log out and back in, or restart Windows, for the change to take effect.

Define The Slow Link Time-Out

Windows uses the “Slow Link Time-Out” value to define what should be classified as low-speed and what a high-speed connection is. The default time-out is 2000 milliseconds; any connection slower is considered a low-speed link.

To elaborate, if the server storing a user’s profile does not respond before the time specified in the value of this entry, then the link to the server is considered to be slow, and it offers the user