

Navigate to:

HLM\SYSTEM\CurrentControlSet\Services\LanmanServer\Parameters

Modify or create the String Value called Autodisconnect and set it to equal the time in minutes before a session is disconnected. This can be between 0 and 4294967295 (0xffffffff in hexadecimal). Restart Windows for the change to take effect.

Set the value to 0xffffffff to disable the disconnection function.

Specify The Idle Timeout For Server Connections

You can specify the amount of idle time that a circuit is allowed before being disconnected. If this parameter is set to a low value, it saves server resources, but reduces performance because of the client overhead in reconnecting.

Navigate to:

HLM\SYSTEM\CurrentControlSet\Services\LanmanServer\Parameters

Create or modify the DWORD value called Disc. Set it to the value in minutes—from 0 to as high as you want. The default is 15.

You may need to restart or log out and back in for the change to take effect.

Specify The Server Announcement Variation

You can specify the time by which the server announcement period can vary. This helps to prevent several servers from continuously announcing simultaneously, thereby reducing network load peaks.

Navigate to:

HLM\SYSTEM\CurrentControlSet\Services\LanmanServer\Parameters