

Fix The Disk Cleanup Tool

When you try to compress old files, the Disk Cleanup tool may stop responding, and you could receive a message like the following:

“Disk Cleanup is calculating how much space you will be able to free on (C:).

This may take a few minutes to complete.

Scanning: Compress old files”

This happens when there’s an incorrect entry in the registry that is used by the Disk Cleanup utility to locate compressed files.

Navigate to:

HLM\SOFTWARE\Microsoft\Windows\CurrentVersion\Explorer\VolumeCaches

Delete the “Compress old files” registry key and you’re done.