



Launch the Wireless Client Setup

8. Plug the USB drive into your other wireless Windows XP SP2 computers, that is, other than the ones where you created the wireless setup configuration. The Removable Disk dialog box will open with various options; select “Wireless Network Setup Wizard using the program provided on the device” and click OK. (If the Removable Disk dialog box doesn’t start, open your USB Drive from Windows Explorer, find the file `setupSNK.exe`, and double-click it).
9. You will be prompted to add the computer to the wireless network. Click OK. The wizard will now configure your computer for wireless access. When it informs you that the computer has been successfully added to the wireless network, click OK.
10. Follow the same procedure for all your other Windows XP SP2 computers.