

tee privacy of the data. While ReadyBoost allows caching to such a Flash drive, all I/O access to the cache need not necessarily go to the Flash cache. For example, if a cache call requires a sequential read access, ReadyBoost will direct the call to the hard drive, instead of the cache on Flash. This is because hard drives are faster at sequential reads than are Flash drives. Random reads, however, are satisfied from the Flash cache.

Another positive implication of ReadyBoost is to laptop owners—Flash access is less costly in terms of battery life than access to a hard drive. This should, in theory, increase battery life of a laptop.

3.8.1.1 Turning ReadyBoost on or off for a storage device

When you insert a compatible portable device, the AutoPlay dialog box will offer you the option to speed up your system using Windows ReadyBoost:

1. Plug a Flash drive or other removable media device into your computer. This should automatically open AutoPlay
2. If AutoPlay does not open, it might have been disabled.
 - To enable AutoPlay click on Start > Control Panel and type 'auto' in the search box in the upper-right corner. Then click on the 'Start or stop using auto-play for all media devices' and then click on the 'Use AutoPlay for all media and devices' check box
 - You can also enable ReadyBoost by right-clicking on your portable device inside Windows Explorer
3. In the AutoPlay window, under the General Options, click 'Speed up my system'



Speed up your PC with ReadyBoost