

Windows on a separate partition for multi-boot. This is your only choice if your computer does not have any operating system. This option also gives you advanced Disk Management features such as Format, Extend partition, Create or Delete partition if you have booted your computer using the Windows Installation Disc and not using the setup.exe from your existing Windows installation

A custom installation does not retain any of your programs or settings. If you delete or formatted the partition that holds your current Operating system, all data on that partition, including programs, files and settings would be permanently deleted once you go with the installation process.

However if you decide not to format or delete the Windows partition and install Windows 7 on top of it, all your user files will be saved in a 'Windows.old' folder automatically on the same partition. While this does not delete your previous files, your encrypted files will be rendered useless in the new Windows. So, we recommend you to back them up before performing a Custom Install. You can delete the 'Windows.old' folder using Disk Cleanup Utility on your Windows partition.

2.2 Install Windows by performing a custom installation

You can choose one of the following options:

- If your computer already has some version of Windows installed and you want to replace it with Windows 7 without making any changes to your partitions, boot into it, insert the Windows 7 installation disc into the DVD drive or mount its image using PowerISO or Daemon tools and the likes. Then open the Autorun File or Setup.exe.
- If your computer doesn't have an operating system installed or if you want to create, extend, delete, or format partitions, you need to restart your computer with the installation disc



First screen of Windows 7. It does not show a progress bar like Vista or XP anymore

inserted in your DVD drive. This causes your computer to start (or "boot") from the installation DVD. If you are asked to press a key to boot from DVD or CD, press any key. For this to appear, ensure that your DVD drive is set