

```

        SharedPreferences sp = getSharedPreferences(preferenceName, 0);

        String autoResponsePref = getString(R.string.autoRespondPref);
        String responseTextPref = getString(R.string.responseTextPref);
        String autoLocPref = getString(R.string.includeLocationPref);
        String respondForPref = getString(R.string.respondForPref);

        boolean autoRespond = sp.getBoolean(autoResponsePref, false);
        String respondText = sp.getString(responseTextPref, "");
        boolean includeLoc = sp.getBoolean(includeLocPref, false);
        int respondForIndex = sp.getInt(respondForPref, 0);

        // Apply the saved settings to the UI
        if (autoRespond)
            respondForSpinner.setSelection(respondForIndex);
        else
            respondForSpinner.setSelection(0);

        locationCheckbox.setChecked(includeLoc);
        responseTextBox.setText(respondText);
    }

```

7. Complete the savePreferences stub to save the current UI settings to a Shared Preferences file.

```

private void savePreferences() {
    // Get the current settings from the UI
    boolean autoRespond =
        respondForSpinner.getSelectedItemPosition() > 0;
    int respondForIndex = respondForSpinner.
        getSelectedItemPosition();
    boolean includeLoc = locationCheckbox.isChecked();
    String respondText = responseTextBox.getText().toString();

    // Save them to the Shared Preference file
    String preferenceName = getString(R.string.user_

```