

home premises. All this is everyday task and problems we need to take care about from time to time. We show you how to get through a few of them.

Networking

No one who has every used internet would like to stay away from it. There are people who spend their whole day on the internet, watching videos, updating their friends and receiving updates, check their emails and what not. For those who are part of an office would be using the network of networks for getting the job done. No matter where we are today, we always want to stay connected. Ubuntu can help your social connection by making your network connections easier, in fact a lot easier.

A network icon is present in the top panel on the right corner. If you have a router to which you are connected by an Ethernet wire (a typical desktop setup for home and office), then chances are you are already into the network. This is behaviour with significant resemblance to the world of Windows. However, unlike Windows, Ubuntu places the controls for modifying your network setting right under an option which you get when you click the network icon on the panel.

Connecting to an Ethernet network with DHCP enabled – In case you do not know, DHCP stands for Dynamic Host Configuration Protocol and is the set of rules which allow a computer on a network to get its IP address from a remote server. The way it works is simple. When a computer is started (in more strict words, when an interface is brought up), it broadcasts the request for getting its IP address. The machine which is responsible for allocation of IP addresses responds and negotiates to send a network address to the machine which broadcasted the packet. It is this technology which allows the computers to get online without having to configure settings for the network. If you are on Ubuntu and want to connect to a DHCP enabled network, you just need to connect the Ethernet wire.

In case you are using DNS servers other than what the DHCP server sends you, it is simple and easy to set it as well. Just click on the networking icon on the top right corner and select 'Edit Connections'. On the new window that opens up, select the 'Auto eth0' (unless you have changed the name already) on the 'Wired' tab and click the 'edit' button. This will open up another window where you will be able to change the settings for the Ethernet network. In the window with title 'Editing Auto eth0' open the 'IPv4 Settings' tab and change the method from 'Automatic (DHCP)' to 'Automatic (DHCP) addresses only'. This should enable the DNS servers input