

3. Select the Internet Connection Settings tab and the system will display a new screen saying you'll be disconnected from the internet. Select "Yes".
4. On the next screen, select "Easy" when the system asks you what kind of installation you want to use.
5. When it asks you what type of connection you have; select "wireless".
6. Select "Scan" on the next screen and the console will search for all available networks in the area.
7. When it completes scanning, select your home network. Select your security settings, enter your encryption key and save your settings.
8. You can test the connection by selecting the "Test Connection" option. If the connection has been made, your network information will appear on the screen.



Sony PlayStation 3

Stream media

Do you know that your PS3 can do more than just online gaming? With a few tweaks to your settings, and some software set up on your computer, you can stream music, videos and photos from your computer to your PS3 over your home network.

To do this, make sure your PS3 is connected to the same network (via ethernet or wirelessly) as your computer. Then, on your PS3 go to **Settings > Network Settings > Media Server Connection** and set it to "Enabled".

► If you have a PC with Windows

1. Open Windows Media Player
2. Go to **Library > Add to Library** and add folders you want your