

and 8-63 alphanumeric characters. You can optionally select the check boxes to hide characters for your security key and save this network for future use.

7. After you're done, click "Next", your ad hoc network will become ready for use! A confirmation page shows your ad hoc network settings.

Now in the "Network And Sharing Center" you can choose what to share as you can see from the screenshot alongside.

In order to Share an Internet Connection, click "View Status" next to the connection that you want to share. Now click on the Properties button which you will find under Activity. Click on the Sharing tab and tick the checkbox where it says "Allow Other Network Computers To Connect Through This Computer's Internet Connection". Under Home Networking Connection select "Wireless network Connection" and click "OK".

You'll see your connection listed under Wireless Network Connection on the other computer. Simply connect from there and you're done sharing the internet connection.

The LAN way

We've already seen how to create a quick ad-hoc wireless connection between two



Your very own Wireless Network



Sharing selectively



Letting others connect through your internet connection