

3. You can switch the mode using the selection switch. Once in USB mode, you can connect your router to your computer with the USB cable provided and power on the device. The Connection Manager should start up automatically.

Now, let's configure the 3G connection.

GotoSettings > Switch to USB Modem ConnMgr

You'll have to set up a new profile. Click on the Profile button.

Click on the New button to create a new profile.

Select your profile type. You can choose Preconfigured settings or create your own User Defined Profile.

If your service provider isn't listed in the preconfigured list, choose User Defined Profile and click on "Next".

Fill in your profile name, phone number, APN, user-name, password and authorisation type. You can get these details from your service provider.

Click "Finish" and you're ready to connect.

You can now connect to the internet by clicking on the black connect button, once connected, it will turn green. To disconnect, click on the green disconnect button.

To configure your Wi-Fi settings:

1. Go to **Settings > Switch to Wi-Fi and Basic Settings** and select "Wi-Fi settings".



Welcome Screen



Select Profile type



Fill your details