

Depending upon what you are shooting and what conditions you are in, you should choose whether you should go for a slow or fast shutter speed. A slow shutter speed is recommended when you're in low light conditions and have a tripod, where you can afford to keep the shutter open much longer. Or, as mentioned before, planning on light painting or capturing light trails. A slow shutter speed also lets you choose a lower ISO value and thus have less noise in your image.

Conversely, a fast shutter speed is useful when you're doing sports photography. A fast shutter can capture moving images much better and can freeze a shot with no blur. Of course, this can only be done when there is plenty of light around.

Shutter speed is measured in seconds. Experiment with the correct

value before you decide which one is appropriate for the moment. Or leave it at automatic if you don't want to be bothered.

White balance

White balance helps remove the color tint left by the light source on objects. You'll often see that when you're shooting indoors under an incandescent light source such as a bulb the scene has a distinct yellowish-orange tint to it. Now all cameras these days have auto white balance, which is designed to analyze the scene and remove the color cast but often it does not do its job properly, which is where the manual controls come in.

If you go through the white balance settings,



Play with White balance to get the perfect tint